

Los Alamos Neutron Science Center (LANSCE) Superconducting RF Structures Lab (SRF Lab) Capabilities

Tsuyoshi Tajima (LANSCE)

Activities in the SRF Lab

- Assembly, tuning and vertical testing of superconducting RF structures for various projects
 - Elliptical cavities, single and multi-cell cavities for high velocity particles
 - Spoke cavities for low velocity particles
- Past and present projects
 - Small-scale tests with 3-GHz 1-cell cavities (~1998)
 - Accelerator Production of Tritium (APT, 1998-2001)
 - Advanced Accelerator Applications (AAA, 2001-2003)
 - New Material study for SRF applications such as MgB_2 (2003-)

Facilities in the SRF Lab

- Cavity tuning and test control room
- Cavity measurement area
 - Cryostats and inserts with removable radiation shield
- Chemical Polishing Facility at MST Division
 - System for elliptical and spoke cavities with BCP solution circulating
 - Maintain the temperature at $<15^{\circ}\text{C}$ with a chiller
- Clean room for clean assembly and rinsing of the cavity
 - 2600 ft² (260 m²) (Class 100 and 1000)
 - High-pressure rinsing system (1000-1500 psi)
 - Ultra-pure water system (2000 gallons/day, 1500-gallon storage tank)
 - Ultrasonic cleaning system (40 kHz, 90 gal. 3 baths)

Facilities at the SRF Lab

2600 ft² class-100 Clean room, 10-ft high



Ultra-pure water with 2000 G/day and 1500 G storage tank



cryostat inserts




140 ft.

Cryostats with movable radian shield




100 ft.




High-pressure rinse in a clean room.

International Linear Collider Workshop, KEK, November 23-15, 2004
Building MPF 17
 Control, tuning

8-Cavity chain for the 12.5m cryomodule






Existing vertical cryostat with 8
TESLA 9-cell cavities in it,
which enables us to test 8
cavities by filling the cryostat
with liquid helium only once

This 2,600 ft² (260 m²) clean room dedicated for assembling SRF cavities.



High-pressure rinsing system. While the cavity is rotating on the turn table at ~ 30 rpm, water jets at 1,000-1500 psi move up and down automatically and rinse off the particles and chemical residues from the inner surface of the cavity.



Shown is a 5-cell
ATP cavity
~1.1m long
~0.4 m in diameter

Ultrasonic cleaning system to degrease, clean, and rinse the components for SC cavities and power couplers in the clean room. (three 90-gallon baths with 40-kHz oscillators)



Ultra-pure water system that can produce 2,000 gallons per day of de-ionized water with a resistivity (purity) of $> 18\text{ M}\Omega\cdot\text{cm}$. Shown in the center is a 1,500-gallon storage tank.



Current HPR of one
TESLA 9-cell cavity
needs ~2000 L (500
gallons)

This has the
capacity of high-
pressure rinse
TESLA 9-cell
cavities 3 times.

38-inch ($\sim 1\text{m}$) diameter, 10-ft ($\sim 3\text{m}$)
deep cryostat with radiation shield





Two 38-inch (~ 1m)
diameter cryostat
inserts.
~2m vertical space
available under the
thermal shield plates.

With minor mods, this
could test up to ~8
TESLA 9-cell cavities
with one fill of liquid
helium (~1500 liters).

What needs to be done to determine whether these facilities are good enough for the ILC cavities?

- Compare the facilities with the ones at DESY and upgrade them if necessary, but if the necessity is uncertain, use the existing one
- High-pressure rinse, re-assemble and measure the performance of some of the high gradient cavities measured at DESY, and compare them with the DESY results. (Since we do not have the EP capability, we cannot go back to EP, but can go back to BCP if necessary.)